

Attention: due to your 4G network communication with your local sim card operator, the voice clips may be have some delays after you sent the request.

5、Related SMS commands

Apn Setup	apn#apn parameter #user name#password#
Modify IP/port	server#ip/domain#port#
Modify device id	deviceid#device id#
Restore to factory setting	1122#
Restore default password	pwrst#
Reboot	sysrst#
Set minutes interval	time#minutes number#
Set seconds interval	md#seconds number#
Require device information	INFO#

SOS button: Press it for 3 seconds the GPS tracker will dial the Number 1 firstly, if the Number 1 no answer, it will dial the Number 2 automatically, if the Number 2 no answer, it will dial the Number 3 automatically.

Tips: To enable the SOS calling function,please preset the Phone number (Number 1,Number 2,Number 3) # in APP, choose the correct answer mode and please make sure the SIM card in the GPS tracker have enough airtime balance.

D. Information(Voice Recorder)

You can click the MIC icon in the App to send voice recording request to the GPS tracker to get voice clips around it, it will send back voice clips soon.

Single recording

3593390756646

TALKBACK ALERT MESSAGE

2018/10/13 14:54

2: Click, listen

1: Click blue icon, display send successfully. Upload 14seconds recorder file to this page

APP voice recording APP--Message

APP Voice-activated loop recording

Settings v1.01

Sound Control

Open

Close

oil and electricity settings

Sound Control

TF card voice recorder (only support with TF card slot)

SMS 111 (SMS recording 10 minutes pause)

command: 222 (voice recording 10 minutes pause, auto recording 10minutes again if any voice, every time 10minutes, cancel send SMS 555)

Read TF card recorder : 1-SMS : 888 , tracker will play the recorder (requir speaker)

2-Take TF card out, put into MP3 player or connect PC

3/24 今天 12:36

111

3/24 今天 12:37

sms sound record

3/24 今天 12:37

222

3/24 今天 12:37

sound record

Geo-fence: You can set a security range on the map in your app, once your GPS tracker out of the preset safe range, you will get alarm.

C. Contact & SOS

This function is for the security of your family members, especially for kids/ elderly to make SOS calling when they need help in emergency.

Emergency calls only

contacts

When the device takes over the SOS button, the device will dial the following numbers

Ans Mode Auto Answer Call

Number 1 Please enter the num

Number 2 Please enter the num

Number 3 Please enter the num

White list

Playback

security scope

Range (100-3000)meters

home 500

school 500

office 500

Close

Close

Close

The difference among the positioning methods are below:

A: GPS positioning: when the GPS tracker stay outdoor/good GPS signal environment, the GPS tracker will show you a accuracy GPS location on the map.

B: Wifi positioning: when you put the GPS tracker in a place where the GPS signal is weak/not available, but the wifi signal is available, for example: in your home/office/mall, the GPS will capture the wifi router IP address and show the wifi location on the map.

C: LBS positioning: when both GPS and Wifi signal are not available for the GPS tracker, it will give you a general location according to the nearest 4G signal tower around it and show that location on the map.

GPS tracker location accuracy:

GPS: normally below 10 meters outdoor.

Wifi: below 100 meters due to the wifi signal valid range . normally can reach 100 meters maximum.

LBS: above 100 meters, normally, if the tracker stay in the city, the LBS location accuracy will be much more accurate than that stay in the countryside.

B. Playback and Geo-fence

Playback: Please choose the start time and end time and other options in the APP to check the historical trace of your GPS tracker and show it on the map as below.

A. Track

3593390750175

Refresh

satellite map

road condition

street view

signal strength, battery positioning mode

longitude latitude

Distance Navigation

Online

GPS

Time 2018-10-09 03:26:12

address: address:Hainaut Province, Walloon Region, Belgium 50.227218,4.229714

GPS:10 norest,1786metro

trackhora: 2019-05-25 09:00:04

Commhora: 2019-05-25 09:00:04

direccion: Calle 92 #192, Medellin, Antioquia, Colombia

trackhora: 2019-04-25 20:27:32

Commhora: 2019-04-25 21:31:01

direccion: Dong Lian Da Sha, Baoan Qu, Shenzhen Shi, Guangdong Sheng, China, 510852

Static

Normal LBS

Positioning Time: 2019-04-08 13:21:32

Address: Nairobi County Nairobi Umjioa Moi Drive

Skymart supermarket

Manyanja Car Wash Bus

Tona

Our device support 3 different positioning methods below:

GPS Location

Wifi Location

LBS location

Login ID: IMEI number.

Password: The last 6 digits of device IMEI.

(If you forgot your device IMEI or password, please contact our after service/sales timely for assistance)

4、Main Functions:

86011

Settings v1.69

Map Settings

Upload interval settings

Modify the password

ON OFF

FAQ

Privacy Policy Statement

Factory data reset

Manual

Log out

Track

Playback

security scope

Health

contacts

Information

Alarm clock

Find device

Not disturb

Power saving

Attendance

Setting

Tips: to make battery work longer time, we suggest you set longer location uploading interval in "Setting"--> "Upload interval settings" and enable the function in "Power saving".

Power off: Press the power key for 9 seconds (3 LED will light on together then off).

3、Login the GPS tracker in APP/Web

When the GPS tracker yellow LED blinking slow, it means the GPS tracker is online and ready to be tracked by mobile APP/PC web:

There is a QR code sticker include 15 digits IMEI with each unit device, the available method to login the APP:

1: Input the device IMEI and password manually.

2: Scan the QR code and it will login the app automatically .

Input 15 digits IMEI

Input password

Default password: The last 6 digits of IMEI

Forgot password

LOGIN

359339078004855

You can also click here and use your phone camera to scan the GPS tracker QR code to login APP GPS365 automatically